



TAILGATE ASSIST SHOCK TAS-0100 INSTRUCTION MANUAL



FOR INSTALLATION ON DRIVER'S SIDE ONLY!

READ THESE INSTRUCTIONS BEFORE USE & KEEP FOR FUTURE REFERENCE

SAFETY INFORMATION

⚠ WARNING

- This product is NOT a substitute for pinning, latching, or locking the tailgate in its upright position; always do so.
- ALWAYS firmly support the opened tailgate if used to hold objects as this product does not make the tailgate weight bearing.
- NEVER raise or lower the tailgate while anyone or anything is under the tailgate.
- When the product is in use, keep hands away from all openings, rollers, and cables.

⚠ CAUTION

Minor adjustments may be necessary to ensure your tailgate lift assist kit works properly due to the many different sizes, weights, and designs of trailers and tailgates. After the initial installation of your tailgate lift, carefully ensure that it is working properly. Check to make sure there is proper tension on your tailgate. Never force the tailgate up or down. It should travel with very little effort in both directions. Always make sure that the cable travels in the grooved portion of the rollers and that the rollers are turning freely during operation.

FITMENT

1999–2006 Chevrolet Silverado and 2007 Chevrolet Silverado Classic

1999–2006 GMC Sierra and 2007 GMC Sierra Classic

PARTS LIST

- 1 × Shock
- 2 × Mount Plates
- 1 × Post
- 2 × Nuts
- 1 × Big Washer
- 1 × Small Washer
- 1 × Tube of Threadlocker
- 1 × Mylar Sheet

13mm Wrench (req. but not incl.)



INSTRUCTIONS

1. Remove the bolt near the tailgate hinge with a 13mm wrench.



2. Use the bolt removed from Step 1 to install the mount plate.



3. Detach the tailgate cable, and then remove the cable bolt with a 13mm wrench.



4. Apply the threadlocking fluid to the threads of the post. Install the post and the big washer where the cable bolt was previously. Tighten the fully threaded end of the post into the truck with a 13mm wrench.



5. Attach the tailgate cable onto the post installed in Step 4.



6. Install the shock by attaching it to the bottom and top mounts as shown. Install a nut with the small washer on the post and a nut on the mount plate stud. Tighten the nut enough to engage the nylon ring but not too much. The parts should still be able to move freely around the stud.



7. The included mylar sheet can prevent components from rubbing against the truck bed and tailgate in the event that parts become loose. Cut the mylar sheet to the required size with a pair of scissors. Apply the mylar sheet to the truck bed and tailgate where tailgate assist parts come into close contact during operation.



The images shown are only examples of how the mylar sheet can be installed on a vehicle. Install according to your specific vehicle.



CONTACT US

Thank you for choosing our products! If you have any questions or comments, contact us at help@cs-supportpro.com and we'll resolve your issue ASAP!

For a .pdf copy of the latest version of these instructions, use the appropriate app on your smartphone to scan the QR code to the right.

