Motorcycle Scissor Jack **Instruction Manual**

Safety Information



Warning!

- The instructions provided herein are only for general information. ALWAYS perform all repairs in full compliance with your motorcycle's service manual.
- **DO NOT** allow children or those unfamiliar with this product to use it. Do not use while under the influence of alcohol, drugs, or any medication that negatively affects your judgment or reflexes. Keep children and bystanders away during use.
- Keep your work site clean and well lit. Cluttered and dark work areas invite accidents.
- **ALWAYS** use personal protective equipment (PPE) suitable to your task. Always wear ANSIapproved eye and hand protection while using this product. Nonslip footwear is also highly recommended. Other equipment such as ear, head, and body protection may also be necessary depending on your work and other equipment.
- Dress properly for motorcycle servicing. Do not wear loose clothing or jewelry and keep hair, clothing, gloves, hoses, and tools away from any moving parts during use.
- Do not overreach. Keep proper footing and balance at all times.
- **NEVER** allow the lifted weight to exceed the 1100 pound (500 kilogram) capacity.
- Maintain this product. Check for misalignment, binding, wear, or other damage before use. If any damage is detected, repair or replace the problematic components before further use. In a large shop, mark such tools **DO NOT USE** until they have been repaired. Only replace components with identical parts.

Specifications

Material		45# Steel, Chrome Vanadium Steel, Rubber	
	Platform & Base	14.7×9.1 in.	37.2×23 cm
Dimensions	Rubber Pad	14.1×8.5 in.	35.7×21.7 cm
	Height	3.7–13.8 in.	9.5–35 cm
Weight Capacity		1100 lb.	500 kg
Net Weight		28.1 lb. · · ·	12.8 kg

Package List

1 × Lifting Jack

1 × T-Handle Wrench

1 × 3/8-Inch Socket

1 × Safety Pin

1 × Bike Chain Brush

2 × Gloves

Operation

- 1. Place the jack on a hard level surface.
- 2. Center your motorcycle above the jack with the jack in its lowest position. Balance weights or safety straps (not included) may be required to properly balance some motorcycles.
- 3. Use the provided wrench or the socket and a ¾" drive ratchet to turn the jack's axle clockwise and slightly raise your motorcycle from the ground.
- 4. Make sure the motorcycle is properly balanced, adjusting as needed.
- 5. Lift the motorcycle the rest of the way to the height required for your work. Insert the safety pin through the holes at the bottom of the jack closest to the jack's feet for extra security. Service your bike as needed.
- 6. After servicing your motorcycle, check that there are no obstructions underneath or between the parts of the jack and then turn the wrench counterclockwise to lower the motorcycle. As you lower the stand, make any necessary adjustments so that the bike reaches the surface in a stable position. Fully lower the jack to its closed position and remove it from under the motorcycle.

Maintenance

- Check the condition of the jack before and after each use. Repair or replace any worn or damaged components before further use.
- The jack can be cleaned with a soft, damp cloth. Do not use abrasive cleaners or caustic chemicals. Allow time for it to air dry before replacing them in the case.
- Store this product in a fully lowered position in a cool, dry place away from direct sunlight and inaccessible to children.

Contact Us

Thank you for choosing our products! If you have any questions or comments, contact us at help@cs-supportpro.com and we'll resolve your issue ASAP!

For a .pdf copy of the latest version of these instructions, use the appropriate app on your smartphone to scan the QR code to the right.

